


Assembling a half floor/fleece floor



Spread out the floor on the desired half of the Nordic tipi. The zip cover must face downwards.



Attach the floor to the tent wall using five toggles. (See the positions marked A in the illustration.)



Pull the toggle through the ring on the tent wall so it holds itself in place.



Place the strap with Velcro across the end of the zip. (See B in the illustration.) This minimises the strain on the zip. A hook peg can be placed in the opening inside the strap, or the strap can be passed around the central pole before it is attached.



To make the floor nicely taut, it is important to stretch the long side of the floor first by tightening the two floor tensioners (see C) on the outside of the Nordic tipi. Then attach hook pegs to the four fastenings on the long side. (See D.) The floor is then stretched with the remaining floor tensioners on the outside of the tent. Make sure the tension is evenly distributed.



Before using the product, please read "Care instructions, hints and advice" at tentipi.com/support

Velcro

Always open Velcro tape gradually by pulling the hook and loop tapes apart lengthways, preferably with a couple of fingers between them. Opening in a transversal direction may damage the seams as the hook and loop tapes attach stronger to each other this way.



Assembling a half floor with a half inner tent




Assemble the inner tent as described in the instructions but without tightening the outer floor tensioners at the end. Assemble the half floor as described on the opposite page but still do not tighten the outer floor tensioners. The ends of the long sides of both the floor and the inner tent (see A in the illustration) are attached to the same ring with toggles. Loosen both of the inner tent's inner floor tensioners. First stretch the floor using the two floor tensioners on the outside of the tent. (See B.) Then stretch the floor of the inner tent using the inner floor tensioners. (See A.) Finally, tighten the remaining outer floor tensioners and make sure the tension is evenly distributed.

By opening part of the zip, the ends of the half floor can be folded away from the tent opening, providing space for, for example, wet shoes. It is also possible to completely remove a quarter floor.

Floor combinations



Without an inner tent, two half floors can be joined together with the Velcro to make a whole floor. Our half floor can also be combined with a half fleece floor. To make a fire in the tent, you can fold away the floor by opening the zip in the middle of each half floor. The zip also makes it possible to remove quarter of the floor to create an uncovered space for dirty shoes, firewood, etc. If required, a quarter floor can be joined to a quarter fleece floor.



Suggested floor and inner tent combinations



Before using the product, please read "Care instructions, hints and advice" at tentipi.com/support

Velcro

Always open Velcro tape gradually by pulling the hook and loop tapes apart lengthways, preferably with a couple of fingers between them. Opening in a transversal direction may damage the seams as the hook and loop tapes attach stronger to each other this way.



www.tentipi.com